

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

RADIO REPEATER SET, RT-1175A/GSQ (NSN 5820-01-349-5286) (EIC N/A)


INCLUDING

MONITOR-PROGRAMMER SET, AN/PSQ-7 (NSN 5895-01-292-0838) (EIC N/A)

SENSOR SET, ANTI-INTRUSION, DT-561A/GSQ (NSN 6350-01-345-3561) (EIC N/A)

SENSOR SET, ANTI-INTRUSION, DT-562A/GSQ (NSN 6350-01-348-3145) (EIC N/A)

SENSOR SET, ANTI-INTRUSION, DT-565A/GSQ (NSN 6350-01-346-7717) (EIC N/A)



Technical Manual

No. 11-5820-1116-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C. October 1993

ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST FOR

REPEATER SET, RT-1175A/GSQ, NSN 5820-01-349-5286 SENSOR SET, DT-561A/GSQ, NSN 6350-01-345-3561 SENSOR SET, DT-562A/GSQ, NSN 6350-01-348-3145 SENSOR SET, DT-565A/GSQ, NSN 6350-01-346-7717 MONITOR-PROGRAMMER SET, AN/PSQ-7, NSN 5895-01-292-0838

Current as of September 1993

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS
You can help improve this manual. If you find any mistakes or if you know of a
way to improve the procedures, please let us know. Mail your letter, DA Form
2028 (Recommended Changes to Publications and Blank Forms), or DA Form
2028-2 located in the back of this manual direct to: US Army Communications
Electronics Command and Fort Monmouth, ATT: AMSEL-LC-LM-LT, Fort
Monmouth, New Jersey 07703-5007. A reply will be furnished to you.

TABLE OF CONTENTS

		Page	Illus/ Figure
Section I.	INTRODUCTION.	1	
Section II.	REPAIR PARTS LIST	1-1	
Group 18	Repeater Set, RT-1175A/GSQ	1-1-	1
	180102 Electronic component assy, A3160050	2-1	2
	180103 Receiver, radio, A3160020		3
Group 19	Monitor-Programmer Set, AN/PSQ-7	4-1	4
	190102 Receiver, radio, A3160020	3-1	3
Group 20	Sensor Set, DT-561A/GSQ	5-1	5
G. 00 P = 0	200101 Electronic component assy, C5088100	6-1	6
	20010101 Electronic component assy, C5088104	7-1	7
	200102 Electronic component assy, C5088101	8-1	8
Group 21	Sensor Set, DT-562A/GSQ	9-1	9
G.00p 2.	210101 Electronic component assy, C5088100	6-1	6
	21010101 Electronic component assy, C5088104	7-1	7
	210102 Electronic component assy, C5088102	10-1	10
	210703 Transducer, motional PU, A3140925	11-1	11

DEPARTMENT OF THE ARMY WESTINGTON, D.C. DOLOGO 1513

launtill training?

100-11-0000-11 att

ORGANIZATIONAL AND DIRECT EURPORT BIANTERANCE HERAIR PARTS AND SPECIAL TOOLS UST

REPLANTE SET, RT-1175A/CBO, NEM 6020-01-540-6328
SENSOR SET, RT-661A/GBO, NEM 6050-01-345-5561
SENSOR SET, OT-662A/CBO, NEM 6050-01-345-5117
SENSOR SET, OT-663A/CBO, NEM 6050-01-345-7117
SENSOR SET, OT-663A/CBO, NEM 6050-01-345-7117

Summer co. of September 1933

PREPORTING ERRORS AND RECOMMENDING LARROVENERGE AND RECOMMENDING ENTRY OF THE PROPERTY OF THE

TABLE OF CONTENTS

	Page 12 of Transport Control C	
	CONTRACTOR REGISTERS AND	

TABLE OF CONTENTS - Continued

		Page	Illus/ Figure
Group 22	Sensor Set, DT-565A/GSQ	12-1	12
	220101 Electronic component assy, C5088100	6-1	6
		7-1	7
	220102 Electronic component assy, C5088103	13-1	13
	2207 IR transducer assy, C5082210	14-1	14
Section III	SPECIAL TOOL LIST (Not applicable)		
Section IV	CROSS-REFERENCE INDEXES	I-1	
		1-1	
	Part number index	1-2	
	Figure and item number index		

SABAR OF CONTENTS - Continued

Seresa Set, DT-BESAKSSO. 220 101 Filestonia component usay, Offder 100 220 1010 Filestonia component lasay, Offder 100 230 101 Filestonia component lasay, Offder 100 230 101 filestonia component serry, Offder 102 230 111 mandalous zorry, Offder 102	

DESCRIPTION FOR THE RESIDENT

91																			

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

SECTION I. INTRODUCTION

1. Scope.

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of organizational, direct support, and general support maintenance of the Repeater Set, Monitor-Programmer Set and Sensor Sets. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

2. General.

In addition to Section I, Introduction, this Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Items listed are shown on the associated illustration(s)/figure(s).
 - b. Section III. Special Tools List. Not applicable.
- c. Section IV. Cross-reference Index. A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. The figure and item number index lists figure and item numbers in alphanumeric sequence and cross-references NSN, FSCM and part numbers.
- 3. Explanation of Columns (Sections II and III).
- a. ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS UST ONCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

SECTION & INTROCUCTION

.00002

relevant less and authorizes apares and repair paris: apacial tools; specal trait, a east sent of and comments and comments apacial support equipment and comments of the Paparis Set, income of the set o

Javonski,

In edotion to Section I, Introduction, this Pupple Ports and Special Tests Unit is divided into the

Supplement Tis past Post to List. A list of spans and repair parts authorized by this FIPSTL IN uses in the performance of maintenance. The list size includes parts which must be removed for or passential of the sufficient process parts. Parts lists are composed of functional process in second/in supplementations and the supplementation of th


Spection III. Special Tools Ust. Not applicable

e Section 13. Cross-interents Index. A list, in National Item Identification number (NIDI) seellance, of all risk-and atom; numbered tierus appropriate. Have all stating, follow at by a list to alcountered
ellance of all pain numbers appearing in the flatings. Have all stock rembers and gain number and
cross-referenced to each lituativation figure and tiem number appointment. The figure and their number
feet that figure and item numbers in appropriate sequence and cross-references MSM, PSCSM and

Exercise of Columns (Sections a and III).

A THE MOLI (Column (1)). Indicates the number used to identify these called out in the Durant.

b. <u>SMR CODE (Column (2))</u>. The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



^{*}Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) <u>Source Code</u>. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follows:

Code	Explanation
PA PB PC** PD > PE PF PG	Stocked items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code. **NOTE: Items coded PC are subject to deterioration.
KD KF > KB	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.

guila octo (Column (2)). The Source, Maintenance, and Recoverability (SMR) and the second containing supplying suppl



Consideration of the Parameter of the Pa

e se se com Cont. The source code tells you haw to get an ilon needed for malinorance, repair.

Explanation !

Stacked Rome; use the applicacle MSN to recipiestroquescen forms with three source codes. They are sufferinged to the controlled with three sources codes entired in the 3d position of the state code.

HALOTE: Harra coded PC are subject to delaholate.

hams with these codes are not to be not satisfied requisitioned in the substitution of the SMR matildenance category ledicated in the 3d position of the SMR code. The complete ist much be not substituted and aroted

Code

Explanation

- MO- (Made at org/ AVUM Level)
- MF- (Made at DS/ AVUM Level)
- MH- (Made at GS Level)
- ML- (Made at Specialized Repair Act (SRA)
- MD- (Made at Depot)

Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in this RPSTL. If the item is authorized to you by the 3d position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.

- AO- (Assembled by org/AVUM Level)
- AF- (Assembled by DS/AVUM Level)
- AH- (Assembled by GS Category)
- AL- (Assembled by SRA)
- AD- (Assembled by Depot)

Items with these codes are not to be requested/
requisitioned individually. The parts that make up the
assembled item must be requisitioned or fabricated and
assembled at the level of maintenance indicated by the
source code. If the 3d position code of the SMR
code authorizes you to replace the item, but the
source code indicates the item is assembled at a
higher level, order the item from the higher level of
maintenance.

- XA Do not requisition an "XA"-coded item. Order its next higher assembly. (Also, refer to the NOTE below.)
- XB If an "XB" item is not available from salvage, order it using the CAGE and part number given.
- XC Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.
- XD Item is not stocked. Order an "XD"-coded item through normal supply channels using the CAGE and part number given, if no NSN is available.


NOTE: Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 700-42.

- (2) <u>Maintenance Code</u>. Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR Code as follows:
- (a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to one of the following levels of maintenance.

Code	Application/Explanation
С	 Crew or operator maintenance done within organizational or aviation unit maintenance.
0	 Organizational or aviation unit category can remove, replace, and use the item.
F	 Direct support or aviation intermediate level can remove, replace, and use the item.
н	- General support level can remove, replace, and use the item.
L	- Specialized repair activity can remove, replace, and use the item.
D	- Depot level can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions.) (NOTE: Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.) This position will contain one of the following maintenance codes.

Code	Application/Explanation
0	 Organizational or (aviation unit) is the lowest level that can do complete repair of the item.
F	 Direct support or aviation intermediate is the lowest level that can do complete repair of the item.
Н	 General support is the lowest level that can do complete repair of the item.
L	 Specialized repair activity is the lowest level that can do complete repair of the item.




Code	Application/Explanation
D	 Depot is the lowest level that can do complete repair of the item.
Z	- Nonreparable. No repair is authorized.
В	 No repair is authorized. (No parts or special tools are authorized for the maintenance of a "B" coded item). However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) Recoverability Code. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR Code as follows:

Recoverability Codes	Application/Explanation
Z	 Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in 3d position of SMR Code.
0	 Reparable item. When uneconomically reparable, condemn and dispose of the item at organizational or aviation unit level.
F	 Reparable item. When uneconomically reparable, condemn and dispose of the item at the direct support or aviation intermediate level.
Н	 Reparable item. When uneconomically reparable, condemn and dispose of the item at the general support level.
D	 Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item not authorized below depot level.
L	 Reparable item. Condemnation and disposal not authorized below specialized repair activity (SRA).
A	 Item requires special handling or condemnation procedures because of specific reasons (e.g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. <u>CAGE (Column (3))</u>. The Commercial and Government Entity (CAGE) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.



d. PART NUMBER (Column (4)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specificiations standards, and inspection requirements to identify an item or range of items.

NOTE: When you use a NSN to requisition an item, the item you receive may have a different part number from the part ordered.

- e. <u>DESCRIPTION AND USABLE ON CODE (UOC) (Column (5))</u>. This column includes the following information:
 - (1) The Federal item name and, when required, a minimum description to identify the item.
- (2) The physical security classification of the item is indicated by the parenthetical entry (insert applicable physical security classification abbreviation, e.g., Phy Sec C1 (C) —Confidential, Phy Sec C1 (S) —Secret, Phy Sec C1 (T) Top Secret).
 - (3) Items that are included in kits and sets are listed below the name of the kit or set.
- (4) Spare/repair parts that make up an assembled item are listed immediately following the assembled item line entry.
- (5) Part numbers for bulk materials are referenced in this column in the line item entry for the item to be manufactured/fabricated.
- (6) When the item is not used with all serial numbers of the same model, the effective serial numbers are shown on the last line(s) of the description (before UOC).
 - (7) The usable on code, when applicable (see paragraph 5, Special information).
- (8) In the Special Tools List section, the basis of issue (BOI) appears as the last line(s) in the entry for each special tool, special TMDE, and other special support equipment. When density of equipments supported exceeds density spread indicated in the basis of issue, the total authorization is increased proportionately.
- (9) The statement "END OF FIGURE" appears just below the last item description in Column 5 for a given figure in both Section II and Section III.
- f. QTY (Column (6)). The QTY (quantity per figure column) indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that the quantity is variable and the quantity may vary from application to application.
- 4. Explanation of Columns (Section IV).
 - a. NATIONAL STOCK NUMBER (NSN) INDEX.
- (1) STOCK NUMBER column. This column lists the NSN by National item identification NSN number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN (i.e., 5305-01-674-1467).

When using this column to locate an item, ignore the first 4 digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

- (2) <u>FIG. column.</u> This column lists the number of the figure where the item is identified/located. The figures are in numerical order in Section II and Section III.
- (3) <u>ITEM column</u>. The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.
- b. <u>PART NUMBER INDEX</u>. Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).
- (1) <u>CAGE column</u>. The Commercial and Government Entity (CAGE) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.
- (2) <u>PART NUMBER column</u>. Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.
- (3) STOCK NUMBER column. This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and FSCM columns to the left.
- (4) <u>FIG. column</u>. This column lists the number of the figure where the item is identified/located in Section II and III.
- (5) <u>ITEM column</u>. The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

c. FIGURE AND ITEM NUMBER INDEX.

- (1) <u>FIG. column.</u> This column lists the number of the figure where the item is identified/located in Section II and III.
- (2) ITEM column. The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.
 - (3) STOCK NUMBER column. This column lists the NSN for the item.
- (4) <u>CAGE column.</u> The Commercial and Government Entity (CAGE) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.
- (5) <u>PART NUMBER column</u>. Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.



5. Special Information.


- a. <u>USABLE ON CODE</u>. The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC:" in the Description Column on the first line applicable item description/nomenclature. Uncoded items are applicable to all models. Usable on codes are not used in the RPSTL.
 - b. FABRICATION INSTRUCTIONS. Not Applicable.
 - c. ASSEMBLY INSTRUCTION. Not Applicable.
 - d. KITS. Not Applicable.
- e. INDEX NUMBERS. Items which have the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the National Stock Number/Part Number Index and the bulk material list in Section II.
- f. <u>ASSOCIATED PUBLICATIONS</u>. The publication(s) listed below pertain to the Repeater Set, Sensor Sets and Monitor-Programmer Set and their components:

Publication	Short Title
TM 11-5820-1116-12	Operator's and Organizational Maintenance Manual for Repeater Set RT-1175A/GSQ
TM 11-6350-293-12	Operator's and Organizational Maintenance Manual for Sensor Sets, Anti-Intrusion, DT-561A/GSQ, DT-562A/GSQ and DT-565A/ GSQ
TM 11-6350-294-12	Operator's and Organizational Maintenance Manual for Monitor- Programmer Set AN/PSQ-7

g. <u>ILLUSTRATIONS – LISTING</u>. Only those parts coded "O" or "F" in the third position of the SMR Code are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational or direct support authorized items appear in this RPSTL.

6. How to Locate Repair Parts

- a. When National Stock Number or Part Number is Not Known.
- (1) <u>First</u>, Using the table of contents, determine the assembly group or subassembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and listings are divided into the same groups.




- (2) Second. Find the figure covering the assembly group or subassembly group to which the item belongs.
- (3) Third. Identify the item on the figure and use the Figure and Item Number Index to find the NSN.

b. When National Stock Number or Part Number is Known:

- (1) <u>First</u>. Using the National Stock Number or the Part Number Index, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence. The part numbers in the Part Number index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the illustration/figure and item number of the item you are looking for.
- (2) <u>Second</u>. Turn to the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

7. Abbreviations.

Abbreviations	Explanation
ASSY	Assembly
BKDN	Breakdown
CAGE	Commercial and Government Entity
CCA	Circuit Card Assembly
NHA	Next Higher Assembly
NIIN	National Item Identification Number (consists of the last 9 digits of the NSN)
RF	Radio Frequency






Figure 1. Repeater Set, RT-1175A/GSQ (Sheet 1 of 2)






Figure 1. Repeater Set, RT-1175A/GSQ (Sheet 2 of 2)



	14 PERFATER OFT RT-11754/CCO	
	GROUP 18 REPEATER SET, RT-1175A/GSQ	
	FIG.1	
		_
0001 PAOZZ 80063 A3184952	TRAY, BATTERY ALTERNATE FOR PLISH	2
	FUSE, INCLOSED LINK	1
0002 PAOZZ 75915 257001 0003 PAOZZ 80058 BA-3058/U	BATTERY, NONRECHRG	i
0003 PAOZZ 80058 BA-3058/U 0004 PAOZZ 57946 C5088159	ANTENNA SUBASSEMBLY	1
0005 PAOZZ 80063 A3160157	ANTENNA ASSEMBLY	1
0006 PAOZZ 80063 SM-D-940813	CABLE, REMOTE ANTENN	2
0007 PADZZ 80063 A3160064	PLATE, ID	1
0008 XBODD 80063 A3160010	COVER, BATTERY	ī
0010 PAODZ 80063 A3160061 0011 PADZZ 80063 A3160149	GASKET	1 2
0012 PADZZ 80063 A3160125	CABLE ASSEMBLY, SPEC	1 2
nn13 PADZZ 81349 M85528/2-12-A-0	PLATE, RETAINING, ELE	12
0014 PADZZ 96906 MS51957-30B	SCREH, MACHINE	16
0015 PADZZ 96906 MS15795-805B	ELECTRONIC COMPONEN	ĭ
0017 PAOZZ 81349 M83461/1-204	0-RING	1
0018 PADZZ 80205 NAS1635-04LE5	SCREW, MACHINE	6
0019 PADZZ 96906 NAS620C4	WASHER, FLAT	8
0020 PADZZ 80063 A3160035	RECEIVER, RADIO	î
0021 PADDD 80063 A3160020 0022 PADZZ 96906 MS51957-28	SCREW, MACHINE	4
0022 PADZZ 96906 MS51957-28 0023 PADZZ 96906 MS15795-805	WASHER, FLAT	4
0024 PADZZ 80063 A3185004	CABLE ASSY, RF	1
0025 PADZZ 80063 A3160070	SHITCH, RADIO FREQUE	2
0026 PADZZ 96906 MS51957-14 0028 XBDZZ 80063 A3160045	HOUSING, ELEC COMP	ī
0028 XBDZZ 80063 A3160045 0029 PADZZ 57946 C5086393	KNOB	1
0030 PADZZ 96906 MS51021-10	SETSCREH	2
0031 PADZZ 80063 A3160127-2	CAP, PROTECTIVE, DUST	5
0032 PADZZ 57946 C5086557	CAP, PROTECTIVE, DUST	2
0033 PADZZ 80063 A3160211 0034 PADZZ 96906 MS15795-805B	WASHER, FLAT	4
0035 PADZZ 96906 MS51957-27B	SCREW, MACHINE	4
0036 PADZZ 96906 MS3212-3	SCREW, MACHINE	9
0037 PADZZ 80063 A3160215	GUIDE, ELECTRICAL CO	4
0038 PADZZ 80063 A3160185-1	LABEL	ī
0039 PADZZ 80063 A3160181 0040 PADZZ 80063 A3184990-3	0-RING	1
0041 PADZZ 80063 A3160075	CABLE ASSEMBLY, RADI	1
0042 PADZZ 80063 A3184989-1	PACKING, PREFORMED	1
0043 PADZZ 80063 A3184990-1	O-RINGCABLE ASSEMBLY-SHIT	1
0044 PADZZ 80063 A3160128 0045 PAOZZ 80063 A3160134	0-RING	i
0045 PAOZZ 80063 A3160134 0046 PAOZZ 80063 A3160140	PAD, CUSHIONING	1
AATA I NOFE AAAAA MATATA		

TM11-5820-1116-20P

(5)

DESCRIPTION AND USABLE ON CODES(UOC) QTY

(4) PART

NUMBER

END OF FIGURE

(6)

SECTION II (1) (2) (3) TEM SMR NO CODE CAGEC

ITEM NO






Figure 2. Electronic Component Assy, A3160050



SECTION II	TM11-58	20-1116-20P
(1) (2) (3)	(4)	(5)
NO CODE CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC) QTY
		GROUP 180102 ELECTRONIC COMPONENT ASSY, A3160050
		FIG.2
0001 XBDDD 80063 0002 PADZZ 80063 0003 PADZZ 57946 0004 PADZZ 57946 0005 PADZZ 57946 0006 PADZZ 57946 0007 PADZZ 57946 0008 PADZZ 57946 0008 PADZZ 57946 0009 PADZZ 96906 0010 PADZZ 80205 0011 PADZZ 96906	A3160063-3 C5088082 C5088085 C5088077 C5086526 C5088158 C5088164-2 MS35338-134 NAS620C2 MS51957-5	HSG ASSY, XMTR/SYNTH. GASKET. CIRCUIT CARD ASSEMB. CIRCUIT CARD ASSEMB. FILTER ASSEMBLY, ELE. LABEL. CABLE ASSEMBLY, RADI. SCREW, EXTERNALLY RE. HASHER, LOCK. HASHER, FLAT. SCREW, MACHINE. NUT, PLAIN, HEXAGON.






Figure 3. Receiver, Radio, A3160020



, SECTION (1)		(4)	0-1116-20P (5)	(6)
ITEM SMR	CAGEC	PART Number	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
•			GROUP 180103 RECEIVER, RADIO, A3160020	
			F10.3	
0004 PADZZ 0005 PADZZ 0006 PADZZ 0007 PADZZ 0008 PADZZ 0010 PADZZ 0011 PADZZ 0012 PADZZ 0013 PADZZ 0014 PADZZ	80063 80063 80063 80063 80063 96906 96906 96906	A3160043 A3160044 A3160025 A3160030 A3160144 MS51957-13 MS15795-803 MS51957-2 MS35338-134 MS15795-844 MS51957-28 NAS620C6L MS51957-6	CHASSIS, ELEC EQUIP. COVER, ELECTRONIC EQ. COVER, ELECTRONIC EQ. CIRCUIT CARD ASSEMB. CIRCUIT CARD ASSEMB. FILTER, BANDPASS. SCREM, MACHINE. MASHER, FLAT. SCREM, MACHINE. HASHER, FLAT. SCREM, MACHINE. HASHER, FLAT. SCREM, MACHINE. HASHER, FLAT. SCREM, MACHINE. LABEL.	6






Figure 4. Monitor-Programmer Set, AN/PSQ-7 (Sheet 1 of 2)







Figure 4. Monitor-Programmer Set, AN/PSQ-7 (Sheet 2 of 2)



(1)	CTION (2)	11(3)	(4)	820-1116-20P (5)	(6)
ITEM NO	SMR	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				GROUP 19 MONITOR-PROGRAMMER SET, AN/PSQ-7	
				FIG.4	
1 2 3	PAOZZ	57946	C5086312 C5086433 BA-3058/U	.CABLE ASSEMBLY, SPEC	1 40

1	PAOZZ	57946	C5086312	. CABL	E AS	SEM	BLY,	SPEC						• •	1
2	PAOZZ		C5086433	.ANTE	NNA.										1
3	PAOZZ	80058	BA-3058/U	BATTE	RY,	NON	RECH	ARG.							40
4	PAOZZ	80063	A3184952	TRAY.	BATI	TERY									2
5		75915		FUSE.	INC	OSE	DLI	NK.							2
2	PAOZZ		A3160061	cov	ER.I	BATT	ERY.								1
9	PAOZA		BA-5557/U	BATT											2
		80063	A3160085	MON-											1
8	XBODD		A3160123	PLAT											1
9	PADZZ	80063		KE	YRO	ARD.	DATA	FN	TRY						ī
10	PADZZ		A3160108	DI	SPL	AY. O	PINE	I EC	TRA	• • •	• • •				ī
11	PADZZ		A3160107	. PAN	E	CONT	POL.	FLE	CT	• • •	• • •	• • •			ī
12	PADDD		A3160100	SCR											12
13	PADZZ	96906	MS51957-30B	WAS											12
14	PADZZ	96906	MS15795-805B												ī
15	PADZZ	80063	A3160063-3	GA											ŧ
16	PADZZ	80205	NAS1635-04LE5	SCR											4
17	PADZZ		NAS620C4	HASHE											- 7
18	PADZZ	80063	A3160095	CIR	COI	I CA	KU_A	122E	mb.	• • •	• • •	• • •	• • •	• •	2
20	PADZZ	96906	MS51957-14	SCR	EW,	MACH	INE.	• • •	• • •	• • •	• • •	• • •	• • •	• •	~
21	PADZZ	96906	MS51957-28	SCR											9
22	PADZZ	96906	MS15795-805	HAS	HER	, FLA	T	• • •		• • •				• •	0
23	PADDD	80063	A3160020	REC	EIV	ER,R	ADIO		• • •	• • •					I
24	XBDZZ	80063	A3160117	HSG	3 AS	SY,	ELEC	, MA	CH.					• •	1
25	PADZZ		A3160184	CAP, P	ROT	ECTI	VE, [DUST							1
26			A3160127-2	CAP	PR.	OTEC	TIVE	E, DU	ST.						1
27		80063		KNC											1
28	PADZZ	96906	MS51021-10	SET	SCR	EW									2
29	PADZZ	80063		CAF	P.PR	OTEC	TIVE	E, DU	ST.						1
30	PADZZ	96906	MS3212-17	SCF	REW.	MACH	IINE.								2
31	PADZZ			ANN	NUNC	IATO)R								1
32	PADZZ		A3160211	. LEV	FR.	LOCK	REL	EAS	Ē						2
33				SCI	FW.	MACH	IINE.								4
	PADZZ	96906 96906		. WAS	HFR	FLA	T								4
34	PADZZ		***************************************	0-											1
35		80063		P/											4
36		80063		sci	DEM	MACH	ITHE		• • •	• • •		• • •			4
37	PADZZ			GU	IDE	FIF	TRI	AL	ĊÙ.	• • •	• • •	• • •	• • •		4
38		80063													4
39				LABE											i
40		80063													î
41		80063		LAI	DEL.		OCK.	T NO	Ė.	• • •	• • •	• • •	• • •	• •	•
43	PADZZ			NU	1,30	LFT	EMBL.	THO	EA.	• • •	• • •	• • •	• • •	• •	ำ
44				CA	DLE	W221	EMPL'	1 - 2 1	111.	• • •			• • •	• •	1
45				CA	BLE	W221	CMD L	1,38	CU.		• • •		• • •	• •	2
46	PADZZ	80063		GA	SKEI						• • • •	• • •	• • •	• •	2
47				PL	ATE,	KE	INIA	NG, E	LE.		• • • •	• • •		• •	~
48	PADZZ	80063	A3160110	CA	BLE	M22	FWP F.	T,KA	IDI.						1



(1)	(2)	(3)	(4)	(5)	(6)
TEM NO	SMR	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				GROUP 190102 RECEIVER, RADIO, A3160020	
				FIG.3	
2 3 5 6 7 8 9 10 11 12 13 14	PADZZ	80063 80063 80063 96906 96906	MS35338-134 MS15795-844 MS51957-28 NAS620C6L MS51957-4	CHASSIS, ELEC EQUIP COVER, FLECTRONIC EQ COVER, ELECTRONIC EQ CIRCUIT CARD ASSEMS FILTER, BANDPASS SCREW, MACHINE WASHER, FLAT SCREW, MACHINE	1 1 1 2 2 10 2 6 6 6 6 9 1






Figure 5. Sensor Set, DT-561A/GSQ (Sheet 1 of 2)






Figure 5. Sensor Set, DT-561A/GSQ (Sheet 2 of 2)



SE	CTION	11	TM11-5	820-1116-20P	
(1)	(2)	(3)	(4)	(5)	(6)
TEM	SMR		PART		ATV
NO	CODE	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	WIT
				GROUP 20 SENSOR SET, DT-561A/GSQ	
				FIG.5	
1	PA077	57946	C5088159	.ANTENNA SUBASSEMBLY	1
			A3160157	ANTENNA ASSEMBLY	1
			SM-D-940813	.CABLE, REMOTE ANTENN	1
4	XBODD	57946	C5088261	SENSOR ASSY	1
5	PADZZ	80063	A3140958	.PLATE, IDENTIFICATIO	1
			C5088106	COVER, BATTERY	1
_		•	C5088153	PAD, CUSHIONING	i
			BA-5557/U	BATTERY, DRY	1
			A3184965-1	GASKET	1
			C5088100	ELECTRONIC COMPONEN	i
			C5088101 257 001	FUSE, INCLOSED LINK	i
			A3184952	TRAY, BATTERY	i
14		00003	N310473E	Inni, varianti, italianti, italia	
15	PAOZZ	80058	BA-3058/U	BATTERY, NONRÉCHRG	20






Figure 6. Electronic Component Assy, C5088100



(1)	CTION (2)	11(2)	(4))-1116-20P	(6)
NO NO	SMR	CAGEC	PART Number	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				GROUP 220101 ELECTRONIC COMPONENT ASSY, C5088100	
				FIG.6	
3 6 6 7 6 6 7 8 9 7 10 11 12 12 13 14 15 12 12 12 12 12 12 12 12 12 12 12 12 12	PADDD PADZZ	\$0063 57946 80063 57946 80063 57946 57946 80063 57946 81349 96906 57946 80063 96906 96906	C5088104 C5088088 A3184990-5 C5088091 A3184989-1 C5088188 MS24693C6 A3140922 A3184938-1 C5088185 C5086393 C5088186 M85528/2-12-A-01 MS51021-10 C5088182 A318498-1 MS15795-804 MS24693-6B MS24693-2B	ELECTRONIC COMPONENCIRCUIT CARD ASSEMB O-RINGCIRCUIT CARD ASSEMB PACKING, PREFORMEDGASKETSCREW, MACHINEHOUSING ASSYJACK, TIPSPACER, SLEEVEKNOBGASKETPLATE, RETAINING, ELESETSCREWCAP, PROTECTIVE, DUST O-RINGHASHER, FLATSCREW, MACHINE SCREW, MACHINE	111111111111111111111111111111111111111






Figure 7. Electronic Component Assy, C5088104



SE (1) TEM	CTION (2) SMR	(2)	TM11-5820 (4) PART)-1116-20P (5)	(6)
NO		CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				GROUP 22010101 ELECTRONIC COMPONENT ASSY, C5088104	
				FIG.7	
2 3 4 5 6 7	PADZZ PADZZ XBDZZ PADZZ PADZZ PADZZ PADZZ	57946 57946 57946 57946 57946 96906	C5088082 C5088085 C5088077 C5088076 C5088158 C5088164-2 MS35338-134 NAS620C2 MS35649-224	CIRCUIT CARD ASSEMB. CIRCUIT CARD ASSEMB. FILTER ASSEMBLY, ELE. HSING ASSY, XMTR/SYN. CABLE ASSEMBLY, RADI. SCREW, EXTERNALLY RE. MASHER, LOCK. MASHER, FLAT. NUT, PLAIN, HEXAGON.	1 1 1 1 12 22 32 10






Figure 8. Electronic Component Assy, C5088101



NO	CODE	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC) QTY
				GROUP 200102 ELECTRONIC COMPONENT ASSY, C5088101
				FIG.8
23 4 5 6 7 8 10 11 12 13 14 15	PADZZ PADZZ XBDDD PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ	57946 57946 57946 80063 57946 96906 57946 57946 57946 57946 57946 80205 80205	NAS1635-04-6 NAS1635-04-8 MS15795-803 C5088168	CIRCUIT CARD ASSEMB 1 CIRCUIT CARD ASSEMB 1 CIRCUIT CARD ASSEMB 1 HOUSING ASSY, MAG 1 GASKET 1 SCREH, EXTERNALLY RE 4 MASHER, FLAT 4 MASHER, LOCK 4 BRACKET, MOUNTING 1 POST, ELECTROMECHANI 2 SCREM, EXTERNALLY RE 4 MASHER, LOCK 12 MASHER, LOCK 12 MASHER, LOCK 12 MASHER, FLAT 4 SCREM, MACHINE 4 SCREW, MACHINE 4 MASHER, FLAT 5 SCREW, SHOULDER 2 CABLE ASSEMBLY, SPEC 1

TM11-5820-1116-20P

END OF FIGURE

(5)

(6)






Figure 9. Sensor Set, DT-562A/GSQ (Sheet 1 of 2)







Figure 9. Sensor Set, DT-562A/GSQ (Sheet 2 of 2)



SE (1) ITEM	CTION (2) SMR	11(3)	TM11-58 (4) PART	(5)	(6)
NO		CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC) GROUP 21 SENSOR SET, DT-562A/GSQ FIG.9	QTY
23456789	PAOZZ PAOZZ PAODD XBODD PADZZ PAOZZ PAOZZ PAOZZ PAOZZ PAOZZ PAOZZ PAOZZ PAOZZ	80063 80063 57946 80063 57946 57946 57946 80058		ANTENNA SUBASSEMBLY ANTENNA ASSEMBLY CABLE, REMOTE ANTENN TRANSDUCER, MOTIONAL SENSOR ASSY PLATE, IDENTIFICATIO POUCH ACCESSORY COVER, BATTERY PAD, CUSHIONING BATTERY, DRY GASKET ELECTRONIC COMPONEN	






Figure 10. Electronic Component Assy, C5088102



SEC (1)	TION (2) SMR	(3)	TM11-582((4) PART	0-1116	-20P	(5)					(6)
NO		CAGEC	NUMBER	DESCR	IPTION	AND U	JSABLE	ON CO	DES(JOC)	QTY
				GROUP ASSY,			CTRONIC	C COMP	ONEN'	r	
						F	[G.10				
23 F F F F F F F F F F F F F F F F F F F	PADZZ PADZ PAD	57946 57946 80063 57946 80063 57946 96906 80063 80205 96906 57946 57946 57946 57946	C5088134 C5088137 C5088140 A3140943 C5088109 A3184965-2 C5088209 MS15795-805B MS35338-136B A3140948 NAS1635-02-6P MS35338-134B C5090051 C5088167 C5088167 C5088167 C5088164-4 MS35338-135 NAS620C4 NAS1635-04-6 NAS1635-04-8 MS15795-803 C5088218 C5088218 C5088218 C5088218 C5088218 C5088218 C5088218 C5088218 C5090052 NAS1635-04-5P MS35338-135B MS15795-803B		RCUITTO RCUITTO RCUITTO USENINGT.E CASHER, VENERALE RASHER, REHER	CARD A CARD A NE ELL ASSY, 	ASSEMB ASSEMB ASSEMB EMENT. CLASS ALLY RI CLASS ALLY RE CLASS ALLY RE CLASS ALLY RE CLASS ALLY RE CLASS ALLY RE CLASS ALLY RE CLASS				111111111111111111111111111111111111111

END OF FIGURE






Figure 11. Transducer, Motional PU, A3140925



SE (1) TEM NO	SMR	II (3) CAGEC	TM11- (4) PART NUMBER	5820-1116-20P (5) DESCRIPTION AND USABLE ON CODES(UGC) QTY	
				GROUP 210703 TRANSDUCER, MOTIONAL PU, A3140925	
				FIG.11	
234567	PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ	80063 96906 96906 80063 80063 80205	A3184962 A3140928 MS35335-57 MS51957-12 A3140927-1 A3140926 NAS1407N6M3 A3140924	CABLE ASSY, SP, ELEC. 1CAP, PROTECTIVE, DUST 1MASHER, LOCK 1SCREH, MACHINE 1TRANSDUCER, MOTIONAL 1HOUSING, ELECTRONIC 1 PIN, SPRING 3CAP, PROTECTIVE, DUST 1	






Figure 12. Sensor Set, DT-565A/GSQ (Sheet 1 of 2)






Figure 12. Sensor Set, DT-565A/GSQ (Sheet 2 of 2)



(1)	CTION (2)	11(3)	(4)	0-1116-20P (5)	(6)
NO	SMR	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				GROUP 22 SENSOR SET, DT-565A/GSQ	
				FIG.12	
5 7 10 11 12 13 14 0001 0003 0004 0006 0007 0008 0009	PADZZ PAODO PAOZZ PAOZA PAOZZ PADDD PAOZZ	57946 57946 57946 80058 80063 57946 57946 80063 57946 80063 57946	C5088265 C5088103 C5088106 C5088153 BA-5557/U A3184965-1 C5088100 C5088159 C5083527 SM-D-940031 C5082210 A3140958 SM-D-940813 C5086586 A3160157	SENSOR ASSYELECTRONIC COMPONENCOVER, BATTERYPAD, CUSHIONINGBATTERY, DRYGASKETELECTRONIC COMPONEN ANTENNA SUBASSEMBLY TRIPOD ASSEMBLY FIELD DEPLOYMENT KI TRANSDUCER, IR PLATE, ID CABLE, REMOTE ANTENN POUCH ACCESSORY ANTENNA ASSEMBLY	1

END OF FIGURE






Figure 13. Electronic Component Assy, C5088103



SECTION II 1) (2) (3)	(4)	20-1116-20P (5)	(6)
EM SMR J CODE CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
		GROUP 220102 ELECTRONIC COMPONENT ASSY, C5088103	
		FIG.13	
1 PADZZ 57946 2 PADZZ 57946 3 XBDDD 57946 4 PADZZ 80063 5 PADZZ 57946 6 PADZZ 96906 7 PADZZ 96906 8 PADZZ 57946 9 PADZZ 57946 10 PADZZ 57946 11 PADZZ 57946 12 PADZZ 57946 13 PADZZ 80203 14 PADZZ 80203 15 PADZZ 80203	C5088192 A3140950 A3184965-2 C5088209 MS15795-805B MS35338-136B C5088098 C5088167 C5088168 C5088164-4 MS35338-135 NAS620C4 NAS1635-04-8 MS15795-803	CIRCUIT CARD ASSEMB. CIRCUIT CARD ASSEMB. HOUSING ASSY, IR GASKET. SCREW, EXTERNALLY RE. HASHER, FLAT. MASHER, LOCK. CABLE ASSEMBLY, SPEC. BRACKET, MOUNTING. SCREW, SHOUL DER. SCREW, EXTERNALLY RE. HASHER, LOCK. HASHER, LOCK. HASHER, FLAT. SCREW, MACHINE. HASHER, FLAT. NUT, PLAIN, HEXAGON.	8






Figure 14. IR Transducer Assy, C5082210



SE	CTION			20-1116-20P	(6)
.1)	(2)	(3)	(4) PART	(5)	(0)
EM IO	CODE	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	YTP
				GROUP 2207 IR TRANSDUCER ASSY, C5082210	
				FIG.14	
102 .03 .04 .05 .06 .07 .08 .09 .10	PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ PADZZ	57946 57946 57946 57946 80063 57946 57946 96906 96906	C5082211 C5082215 C5082220 C5082221 C5082222 SM-C-940422 C5089998 C5089999 C5090041 MS16629-3077 MS90064-11 MS16995-3B C5086219	CABLE ASSEMBLY, SPEC. RING, COMPRESSION, SE. SIGHT, FRONT. CLAMP ASSY, RTNG. DETECTOR, PYROELECTR. LENS, SENSOR. BUSHING, ELECTRICAL. HOUSING. SPACER, SLEEVE. RING, RETAINING. PACKING, PREFORMED. SCREW, CAP, SOCKET HE. HASHER, FLAT.	1 1 1 1 1 1 6

END OF FIGURE



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

STOCK NUMBER	FIG	ITEM	STOCK NUMBER	FIG	ITEM
5305-00-031-1042	6	22	5310-00-409	13	6
5305-00-340-4748	6	22	5310-00-409	0001	15
5330-01-385-1066	0006	1	5310-00-409	0001	34
5310-00-043-4708	7	8	5305-00-448	4	33
5310-00-043-4708	7	8	5305-00-448	0001	35
5310-00-043-4708	7	8	5305-00-469	4	13
5310-00-054-0041	3	13	5305-00-469	0001	14
5310-00-054-0041	0003	13	5305-00-470	0014	12
5305-00-054-5636	3	9	5305-00-498	8	15
5305-00-054-5636	0003	9	5305-00-498	10	20
5305-00-054-5638	3	14	5310-00-595	3	8
5305-00-054-5638	0003	14	5310-00-595	8	17
5305-00-054-5639	7	9	5310-00-595	10	22
5305-00-054-5639	7	9	5310-00-595	13	15
5305-00-054-5639	0002	11	5310-00-595	0003	8
5305-00-054-5646	11	4	5305-00-655	4	28
5305-00-054-5647	3	7	5305-00-655	6	13
5305-00-054-3648	4	20	5305-00-655	6	13
5305-00-054-5648	0001	26	5305-00-655	6	13
5305-00-054-6652	3	12	5305-00-655	0001	30
5305-00-054-6652	4	21	5310-00-722	4	22
5305-00-054-6652	0001	22	5310-00-722	0001	23

CROSS-REFERENCE INDEXES

STOCK NUMBER	FIG	ITEM	STOCK NUMBER	FIG	ITEM
5310-00-057-0573	4	17	5310-00-782	6	21
5310-00-057-0573	8	14	5310-00-782	6	21
5310-00-057-0573	10	19	5305-00-855	4	37
5310-00-057-0573	13	13	5305-00-855	0001	36
5310-00-057-0573	0001	19	5310-00-878	4	43
5310-00-058-3599	11	3	5330-00-883	0014	11
5305-00-068-6605	6	8	5310-00-928	3	10
5305-00-068-6605	6	8	5310-00-928	7	7
5305-00-068-6605	6	8	5310-00-928	7	7
5310-00-177-1301	10	12	5310-00-928	7	7
5310-00-194-3647	10	29	5310-00-928	0002	9
5303-00-197-8987	8	16	5310-00-928	0003	10
5305-00-197-8987	10	21	5310-00-933	8	13
5305-00-197-8987	13	14	5310-00-933	10	18
5310-00-208-3786	13	16	5310-00-933	13	12
5310-00-224-0746	10	28	6135-00-935	4	3
5310-00-224-0747	8	8	6135-00-935	5	15
5310-00-224-0747	10	9	5920-01-382	5	16
5310-00-224-0747	13	7	6135-00-935	5	18
5305-00-340-4748	6	22	6135-00-935	0001	3
5305-00-340-4748	6	22	5310-00-938	7	10
5305-00-340-4748	6	22	5310-00-938	7	10
5305-00-404-1405	10	27	5310-00-938	7	10
5310-00-409-1763	4	14	5310-00-938	0002	12
5310-10-409-1763	4	34	5305-00-939	4	30



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

STOCK NUMBER	FIG	ITEM	STOCK NUMBER	FIG	ITEM
5310-00-409-1763	8	7	5305-01-020	4	16
5310-00-409-1765	10	8	5305-01-020	0001	18
5315-01-050-9183	11	7	6695-01-383	9	4
6135-01-088-2707	4	1	5895-01-383	4	12
6135-01-088-2707	4	7			
6135-01-088-2707	5	9			
6135-01-088-2707	9	10			
6135-01-088-2707	12	12			
	0001	1		-	
5305-01-108-4414	10	11			
5845-01-175-7277	0012	4			
5995-01-175-7331	4	1			
6145-01-184-5600	5	3			
6145-01-184-5600	9	3			
6145-01-184-5600	0001	6			
5998-01-375-6333	0012	7			
5985-01-184-5621	4	2			
6350-01-237-8089	0014	5			
6350-01-237-8090	0012	2			
5995-01-237-8119	0014	1			
8105-01-239-4196	9	7			
8105-01-239-4196	0012	8			
6210-01-263-1628	0014	6			
5365-01-263-5411	0014	2			
5365-01-265-4863	0014	10			
5310-01-289-0708	3	11			



TM11-5820-1116-20P


CROSS-REFERENCE INDEXES

STOCK NUMBER	FIG	ITEM	STOCK NUMBER	FIG ITEM
5310-01-289-0708	0003	11		
1055-01-329-1773	0014	3		
5935-01-342-9706	4	47		
5305-00-655-9246	6	13		
5935-01-342-9706	6	16		
5935-01-342-9706	6	16		
5935-01-342-9706	0001	13		
5998-01-374-8605	0001	16		
5895-01-374-8660	4	23	_	
5895-01-374-8660	0001	21		
5998-01-375-6331	5	11		
5998-01-375-6331	9	12		
5998-01-375-6331	12	14		
5998-01-375-6332	6	2		
5998-01-375-6332	6	2		
5998-01-375-6332	6	2		
5998-01-375-6333	12	7		
5998-01-375-6335	6	3		
5998-01-375-6335	6	3		
5998-01-375-6335	6	3		
5998-01-376-2219	9	13		
5998-01-376-2220	5	12		
5998-01-376-2232	8	1		
5998-01-376-2233	8	2		
5998-01-376-2234	8	3		
5920-01-382-4861	0001	2		



CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
1	1	6160-01-385-4447	80063	A3184952
1	1	6135-01-088-2707	80058	BA-5557/U
1	2	5920-01-382-4861	75915	257001
1	3	6135-00-935-2587	80058	BA-3058/U
1	4	5985-01-385-1679	57946	C5088159
1	5	5985-01-385-1683	80063	A3160157
1	6	6145-01-184-5600	80063	SM-D-940813
1.	7	,	80063	A3160064
1	8		80063	A3160010
1	10		80063	A3160061
1	11		80063	A3160149
1	12	5995-01-385-4445	80063	A3160125
1	13	5935-01-342-9706	81349	M85528/2-12-A-01
1	14	5305-00-469-5382	96906	MS51957-30B
1	15	5310-00-409-1763	96906	MS15795-805B
1	16	5998-01-374-8605	80063	A3160050
1	17		81349	M83461/1-204
1	18	5305-01-020-0175	80205	NAS1635-04LE5
1	19	5310-00-057-0573	96906	NAS620C4
1	20	5998-01-385-5963	80063	A3160035
1	21	5895-01-374-8660	80063	A3160020
1	22	5305-00-054-6652	96906	MS51957-28
1	23	5310-00-722-5998	96906	MS15795-805
1	24		80063	A3185004
1	25		80063	A3160070
1	26	5305-00-054-5648	96906	MS51957-14
1	28		80063	A3160045
1	29	5355-01-385-3837	57946	C5086393




TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
1	30	5305-00-655-9246	96906	MS51021-10
1	31	5340-01-385-4438	80063	A3160127-2
1	32		57946	C5086557
1	33		80063	A3160211
1	34	5310-00-409-1763	96906	MS15795-805B
1	35	5305-00-448-6547	96906	MS51957-27B
1	36	5305-00-855-2996	96906	MS3212-3
1	37		80063	A3160215
1	38		80063	A3160185-1
1	39		80063	A3160181
1	40	•	80063	A3184990-3
1	41		80063	A3160075
1	42		80063	A3184989-1
1	43		80063	A3184990-1
1	44		80063	A3160128
1	45		80063	A3160134
1	46		80063	A3160140
2	1		80063	A3160055
2	2		80063	A3160063-3
2	3	5985-01-385-1792	57946	C5088082
2	4	5998-01-385-1691	57946	C5088085
2	5	5915-01-385-0783	57946	C5088077
2	6	5305-01-385-3846	57946	C5086526
2	7	5995-01-385-4452	57946	C5088158
2	8	5305-01-385-3846	57946	C5088164-2
2	9	5310-00-928-2690	96906	MS35338-134
2	10	5995-01-385-4452	80205	NAS620C2
2	11	5305-00-054-5639	96906	MS51957-5
2	12	5310-00-938-2013	96906	MS35649-224

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
3	1		80063	A3160042
3	2	5895-01-385-1703	80063	A3160043
3	3	5895-01-385-1704	80063	A3160044
3 [27]	5	5998-01-385-1727	80063	A3160030
3	6	5915-01-385-0874	80063	A3160144
3	7	5305-00-054-5647	96906	MS51957-13
3	8	5310-00-595-6211	96906	MS15795-803
3	9	5305-00-054-5636	96906	MS51957-2
3	10	5310-00-928-2690	96906	MS35338-134
3	11	5310-01-289-0708	96906	MS15795-844
3	12	5305-00-054-6652	96906	MS51957-28
3	13	5310-00-054-0041	80205	NAS620C6L
3	14	5305-00-054-5638	96906	MS51957-4
3	15		57946	C5086526
3	1		80063	A3160042
3	2	5895-01-385-1703	80063	A3160043
3	3	5895-01-385-1704	80063	A3160044
3	4	5998-01-385-1682	80063	A3160025
3	5	5998-01-385-1727	80063	A3160030
3	6	5915-01-385-0874	80063	A3160144
3	7	5305-00-054-5647	96906	MS51957-13
3	8	5310-00-595-6211	96906	MS15795-803
3	9	5305-00-054-5636	96906	MS51957-2
3	10	5310-00-928-2690	96906	MS35338-134
3	11	5310-01-289-0708	96906	MS15795-844
3	12	5305-00-054-6652	96906	MS51957-28
3	13	5310-00-054-0041	80205	NAS620C6L
1	14	5305-00-054-5638	96906	MS51957-4
3	15		57946	C5086526




CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
4	1	5995-01-175-7331	57946	C5086312
4	1	6135-01-088-2707	80858	BA-5557/U
4	2	5985-01-184-5621	57946	C5086433
4	3	6135-00-935-2587	80058	BA-3058/U
4	4		80063	A3184952
4	5	5920-01-382-4861	75915	257 001
4	6	6150-01-385-4449	80063	A3160061
4	7	6135-01-088-2707	80058	BA-5557/U
4	8		80063	A3160085
4	9		80063	A3160123
1	10		80063	A3160108
1	11	5980-01-385-1732	80063	A3160107
4	12	5895-01-383-7638	80063	A3160100
4	13	5305-00-469-5382	96906	MS51957-30B
4	14	5310-00-409-1763	96906	MS15795-805B
4	15	5330-01-385-1665	80063	A3160063-3
4	16	5305-01-020-0175	80205	NAS1435-04LE5
4	17	5310-00-057-0573	96906	NAS620C4
4	18	5998-01-385-1685	80063	A3160095
4	20	5305-00-054-5648	96906	MS51937-14
4	21	5305-00-054-6652	94906	MS51957-28
4	22	5310-00-722-5998	96906	MS15795-805
4	23	5895-01-374-8660	80063	A3160020
4	24		80063	A3160117
4	25	5340-01-385-2328	80063	A3160184
4	26	5340-01-385-4438	80063	A3160127-2
4	27	5355-01-385-3500	80063	A3160210
4	28	5305-00-655-9246	96906	MS51021-10

TM11-5820-1116-20P

CROSS-REFERENCE INDEXES


FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
4	29	5340-01-385-4437	80063	A3160127-1
4	30	5305-00-939-0493	96906	MS3212-17
4	31		80063	A3185006
4	32	5340-01-385-3834	57946	A3160211
4	33	5305-00-448-6547	96906	MS51957-27B
4	34	5310-00-409-1763	96906	MS15795-805B
4	35	5330-01-385-1051	80063	A31601 34 -1
4	36	5340-01-385-2756	80063	A3160140
4	37	5305-00-855-2996	96906	MS3212-3
4	38		80063	A3160215
4	39	5330-01-385-1048	80063	A3160185-1
4	40		80063	A3185001
4	41		80063	A3160181
4	43	5310-00-878-9518	80205	NAS1291C06M
4	44		80063	A3160128
4	45	5995-01-385-4445	80063	A3160125
4	46	5330-02-385-0466	80063	A3160149
4	47	5935-01-342-9706	81349	MS5528/2-12-A-01
4	48		80063	A3160110
5	1	5985-01-385-1679	57946	C5088159
5	2	5985-01-385-1683	80063	A3160157
5	3	6145-01-184-5600	80063	SM-D-940813
5	4		57946	C5088261
5	5		80063	A3140958
5	7		57946	C5088106
5	8	5340-01-385-2080	57946	C5888153
5	9	6135-01-088-2707	80058	BA-5557/U
5	10	5340-01-385-2051	80063	A3184965-1
5	11	5998-01-375-6331	57946	C5088100



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
5	12	5998-01-376-2220	57946	C5088101
5	13	5920-01-382-4861	75915	257 001
5	14	5920-01-382-4861	75915	257 001
5	14	6160-01-385-4447	80063	A3184952
5	15	6160-01-385-4447	80063	A3184952
5	15	6135-00-935-2587	80058	BA-3058/U
5	16	5920-01-382-4861	75915	257 001
5	16	6135-00-935-2587	80058	BA-3058/U
5	17	6160-01-385-4447	80063	A3184952
5	18	6135-00-935-2587	80058	BA-3058/U
6	1	5330-01-385-1066	80063	A3184989-1
6	2	5998-01-375-6332	80063	C5088104
6	2	5998-01-375-6332	80063	C5088104
6	2	5998-01-375-6332	80063	C5088104
6	3	5998-01-575-6335	57946	C5088088
6	3	5998-01-375-6335	57946	C5088088
6	3	5998-01-375-6335	57946	C5088088
6	4		80063	A3184990-5
6	4		80063	A3184990-5
6	4		80063	A3184990-5
6	5	5998-01-385-1694	57946	C5088091
6	5	5998-01-385-1694	57946	C5088091
6	5	5998-01-385-1694	57946	C5088091
6	6	5330-01-385-1066	80063	A3184989-1
6	6	5330-01-385-1066	80063	A3184989-1
6	6	5330-01-385-1066	80063	A3184989-1
6	6	5330-01-385-1066	80063	A3184989-1
6	7	5330-01-385-1633	57946	C5088188
6	7	5330-01-385-1633	57946	C5088188



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
6	7	5330-01-385-1633	57946	C5088188
6	8	5305-00-068-6605	96906	MS24693C6
6	8	5305-00-068-6605	96906	MS24693C6
6	8	5305-00-068-6605	96906	MS24693C6
6	9		57946	A3140922
6	9		57946	A3140922
6	9		57946	A3140922
6	10	5310-01-385-3796	80063	A3184937-1
6	10		80063	A3184938-1
6	11	5340-01-385-2081	57946	A3140923
6	11	5340-01-385-2081	57946	A3140923
6	11	5340-01-385-0153	57946	C5088185
6	12	5355-01-385-3837	57946	C5086393
6	12	5355-01-385-3837	57946	C5086393
6	12	5355-01-385-3837	57946	C5086393
6	12	5355-01-385-3837	57946	C5086393
6	12	5330-01-385-0930	57946	C5088186
6	13	5305-00-655-9246	96906	MS51021-10
6	13	5305-00-655-9246	96906	MS51021-10
6	13	5305-00-655-9246	96906	MS51021-10
6	13	5935-01-342-9706	81349	M85528/2-12-A-01
6	14	5340-01-385-2051	57946	C5088182
6	14	5340-01-385-2051	57946	C5088182
6 .	14	5340-01-385-2051	57946	C5088182
6	15	5330-01-385-1063	80063	A3184998-1
6	15	5330-01-385-1063	80063	A3184998-1
6	15	5330-01-385-1063	80063	A3184998-1
6	16	5935-01-342-9706	81349	M85528/2-12-A-01
6	16	5935-01-342-9706	81349	M85528/2-12-A-01

TM11-5820-1116-20P


CROSS-REFERENCE INDEXES

FIG '	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
6	17	5330-01-385-0930	57946	C5088186
6	17	5330-01-385-0930	57946	C5088186
6	19		80063	A3184938-1
6	19		80063	A3184938-1
6	20	5340-01-385-0153	57946	C5088185
6	20	5340-01-385-0153	57946	C5088185
6	21	5310-00-782-1349	96906	MS15795-804
6	21	5310-00-782-1349	96906	MS15795-804
6	21	5310-00-782-1349	96906	MS15795-804
6	22	5305-00-031-1042	96906	MS24693-2B
6	22	5305-00-340-1042	96906	MS24693-2B
6	22	5305-00-340-4748	96906	MS24693-6B
6	22	5305-00-340-4748	96906	MS24693-6B
6	22	5305-00-340-4748	96906	MS24693-6B
6	1	5305-00-031-1042	96906	MS24693-2B
6	10	5310-01-385-3796	80063	A3184937-1
7	1	5998-01-385-1729	57946	C5088082
7	1	5998-01-385-1729	57946	C5088082
7	1	5998-01-385-1729	57946	C5088082
7	2	5998-01-385-1691	57946	C5088085
7	2	5998-01-385-1691	57946	C5088085
7	2	5998-01-385-1691	57946	C5088085
7	3	5915-01-385-0783	57946	C5088077
7	3	5915-01-385-0783	57946	C5088077
7	3	5915-01-385-0783	57946	C5088077
7	4		57946	C5088076
7	4		57946	C5088076
7	4		57946	C5088076
7	5	5995-01-385-4452	57946	C5088158

TM11-5820-1116-20P

CROSS-REFERENCE INDEXES


FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
7	5	5995-01-385-4452	57946	C5088158
7	5	5995-01-385-4452	57946	C5088158
7	6	5305-01-385-3846	57946	C5088164-2
7	6	5305-01-385-3846	57946	C5088164-2
7	6	5305-01-385-3846	57946	C5088164-2
7	7	5310-00-928-2690	96906	MS35338-134
7	7	5310-00-928-2690	96906	MS35338-134
7	7	5310-00-928-2690	96906	MS35338-134
7	8	5310-00-043-4708	80205	NAS620C2
7	8	5310-00-043-4708	80205	NAS620C2
7	8	5310-00-043-4708	80205	NAS620C2
7	9	5305-00-054-5639	96906	MS51957-5
7	9	5305-00-054-5639	96906	MS51957-5
7	10	5310-00-938-2013	96906	MS35649-224
7	10	5310-00-938-2013	96906	MS35649-224
7	10	5310-00-938-2013	96906	MS35649-224
8	1	5998-01-376-2232	57946	C5088125
8	2	5998-01-376-2233	57946	C5088206
8	3	5998-01-376-2234	57946	C5090076
8	4		57946	C5088107
8	5	5330-01-385-4714	80063	A3184965-2
8	6	5305-01-385-3810	57946	C5088209
8	7	5310-00-409-1763	96906	MS15795-805B
8	8	5310-00-224-0747	96906	MS35338-136B
8	10	5340-01-385-2455	57946	C5088167
8	11	5340-01-385-2745	57946	C5088169
8	12	5305-01-385-3845	57946	C5088164-4
8	13	5310-00-933-8118	96906	MS35338-135
8	14	5310-00-057-0573	80205	NAS620C4



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
8	15	5305-00-498-1261	80205	NAS1635-04-6
8	16	5305-00-197-8987	80205	NAS1635-04-8
8	17	5310-00-595-6211	96906	MS15795-803
8	. 18	5305-01-385-3445	57946	C5088168
8	9		57946	C5088098
9	1		57946	C5088159
9	2	5985-01-385-1683	80063	A3160157
9	3	6145-01-184-5600	80063	SM-D-940813
9	4	6695-01-383-4334	80063	A3140925
9	5		57946	C5088262
9	6		80063	A3140958
9	7	8105-01-239-4196	57946	C5086586
9	8		57946	C5088106
9	9	5340-01-385-2080	57946	C3088153
9	10	6135-01-088-2707	80058	BA-5557/U
9	11	5330-01-385-1655	80063	A3184965-1
9	12	5998-01-375-6331	57946	C5088100
9	13	5998-01-376-2219	57946	C5088102
10	1	5998-01-385-1728	57946	C5088134
10	2	5998-01-385-1698	57946	C5088137
10	3	5998-01-385-1696	57946	C5088140
10	4		80063	A3140943
10	5		57946	C5088109
10	6	5330-01-385-4714	80063	A3184965-2
10	7	5305-01-385-3810	57946	C5088209
10	8	5310-00-409-1763	96906	MS15795-805B
10	9	5310-00-224-0747	96906	MS35338-136B
10	10	5340-01-385-2754	80063	A3140948
10	11	5305-01-108-4414	80205	NAS1635-02-6P



TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
10	12	5310-00-177-1301	96906	MS35338-134B
10	13	5310-01-385-3464	57946	C5090051
10	14		57946	C5088098
10	15	5340-01-385-2455	57946	C5088167
10	16	5340-01-385-2745	57946	C5088169
10	17	5305-01-385-3845	57946	C5088164-4
10	18	5310-00-933-8118	96906	MS35338-135
10	19	5310-00-057-0573	80205	NAS620C4
10	20	5305-00-498-1261	80205	NAS1635-04-6
10	21	5305-00-197-8987	80205	NAS1635-04-8
10	22	5310-00-595-6211	96906	MS15795-803
10	23	5305-01-385-3445	57946	C5088168
10	24	5998-01-385-1695	57946	C5088218
10	25	5340-01-385-0189	57946	C5088250
10	26	5965-01-385-0910	57946	C5090052
10	27	5305-00-404-1405	80205	NAS1635-04-5P
10	28	5310-00-224-0746	96906	MS35338-135B
10	29	5310-00-194-3647	96906	MS15795-803B
11	1		80063	A3184962
11	2	5340-01-385-2735	80063	A3140928
11	3	5310-00-058-3599	96906	MS35335-57
11	4	5305-00-054-5646	96906	MS51957-12
11	5	6695-01-385-3860	80063	A3140927-1
11	6		80063	A3140926
11	7	5315-01-050-9183	80205	NAS1407N6M3
11	8	5340-01-385-2153	57946	A3140924
12	5		57946	C5088265
12	5		57946	C5088265
12	7	5998-01-375-6333	57946	C5088103

EDECK REPERTURE TRANS

	Britis o			
		8475-880-10-0102.		
		0810-00-224-0740		
\$364575A				
	1, 1,800%			
			Tr.	
	60208)		1,	
			81	
		1997-1997-19		
00169050-	89619		21	

TM11-5820-1116-20P

CROSS-REFERENCE INDEXES

FIG	ITEM	STOCK NUMBER	CAGEC	PART NUMBER
12	10		57946	C5088106
12	11	5340-01-385-2080	57946	C5088153
12	12	6135-01-088-2707	80058	BA-5557/U
12	13	5330-01-385-1655	80063	A3184965-1
12	14	5998-01-375-6331	57946	C5088100
12	1	5985-01-385-1679	57946	C5088159
12	2	6350-01-237-8090	57946	C5083527
12	3	6350-01-292-0840	80063	SM-D-940031
12	4	5845-01-175-7277	57946	C5082210
12	6		57946	A3140958
12	7	6145-01-184-5600	80063	SM-D-940813
12	8	8105-01-239-4196	57946	C5086586
12	9	5985-01-385-1683	80063	A3160157
13	1	5998-01-385-1690	57946	C5088189
13	2	5998-01-385-1689	57946	C5088192
13	3		57946	A3140950
13	4	5330-01-385-4714	80063	A3184965-2
13	5	5305-01-385-3810	57946	C5088209
13	6	5310-00-409-1763	96906	MS15795-805B
13	7	5310-00-224-0747	96906	MS35338-136B
13	8		57946	C5088098
13	9	5340-01-385-2455	57946	C5088167
13	10	5340-01-385-3455	57946	C5088168
13	11	5305-01-385-3845	57946	C5088164-4
13	12	5310-00-933-8118	96906	MS35338-135
13	13	5310-00-057-0573	80205	NAS620C4
13	14	5305-00-197-8987	80205	NAS1635-04-8
13	15	5310-00-595-6211	96906	MS15795-803
13	16	5310-00-208-3786	80203	NAS671C4

TOC-0711-0526-21507

VI HOUTSEE

CROSS-RETURNED NUMBER

MICH SENTING METH CHA DRUGE

	STECK NUMBER	
	8735-07-088-2707	
		1 3.0
		26
	/	
	ENT 0.003 A 020 T 743	